

***POWERTECH***

SL2380

# 12/24V Adjustable Reading Light



Instruction Manual

## MODELS:

### Normal

#### Power Loading

1. The main light OFF, blue light ON
2. Short touch once, the main light ON, blue light OFF
3. First time long touch less than 6s, the main light dimming from 100% to 10%
4. The second times long touch less than 6s, the main light dimming from 10% to 100%
5. Short touch again, the main light OFF, blue light ON
6. The third times short touch, the main light ON, and keep with the latest brightness, blue light OFF

#### Power Off

All lights OFF

### Peaceful

#### Power Loading

1. The main light OFF, blue light ON
2. Short touch once, the main light ON, blue light OFF
3. First time long touch less than 6s, the main light dimming from 100% to 10%
4. The second times long touch less than 6s, the main light dimming from 10% to 100%
5. Long touch more than 6s, while main light is on, the main light will **fast flash 3 times** and ON with 100% brightness
6. Short touch again, **the main light OFF, blue light OFF**
7. The third times short touch, the main light ON, keep with the latest brightness, blue light still OFF
8. Long touch more than 6s again to return to **Normal Model.**

#### Power Off

All lights OFF

## PRODUCT SPECIFICATIONS:

Input:	12-30VDC 1.2A Max
Main Light:	3W
Dimming:	10% - 100%
USB Charger	
Power:	10W Max
Output:	5V $\equiv$ 2A Max

Distributed by:  
Electus Distribution Pty Ltd  
46 Eastern Creek Dr,  
Eastern Creek NSW 2766 Australia  
Ph 1300 738 555  
Int'l +61 2 8832 3200  
Fax 1300 738 500

[www.electusdistribution.com.au](http://www.electusdistribution.com.au)