


NEXTECH

XC5138



Wireless Keyboard with Bluetooth®

Instruction Manual

CONTENTS

General Information & Safety Instructions.....	3
Box Contents	3
Product Diagram.....	3
Before First Use.....	4
Operation Instructions.....	4
Cleaning, Care, Storage & Maintenance.....	5
Specifications.....	5
Warranty Information.....	6

GENERAL INFORMATION & SAFETY INSTRUCTIONS


- Do not use in restricted areas
- Dispose of responsibly
- Dispose of exhausted batteries responsibly
- Maximum range based off line of sight
- Children should use with adult supervision
- Keep away from sharp weapons.
- Keep way from moist or damp area.
- Prohibit heavy weight extrusion.
- Prohibit impact, bending keyboard.
- Keep away from oil,chemical or other organic solvents.

WARNING: The manufacturer is not responsible for any potential injury from misuse

BOX CONTENTS

- 1x Wireless Keyboard with Bluetooth®
- 2x AAA Batteries
- 1x User Manual

PRODUCT DIAGRAM



BEFORE FIRST USE

Prior to using your product, please read all the safety and operating instructions thoroughly. Please ensure you follow the steps below before using the product. We recommend you keep the original packaging for storing the product when not in use. Please pay close attention to the section entitled Important Safety and General Instructions. Find a safe and convenient place to keep this instruction manual for future reference.

Unpack the product but keep all packaging materials until you have made sure your new product is undamaged and in good working order. Ensure you have all accessories listed in this manual. Plastic wrapping can be a suffocation hazard for babies and children so ensure all packaging materials are out of their reach.

WARNING: The manufacturer is not responsible for any potential injury from misuse

OPERATION INSTRUCTIONS

1. Install the battery into battery compartment. Red LED Here will blink after battery assembling successfully it means keyboard has power.
2. Turn the power switch on keyboard back to "ON", power is ON
3. Press "Connect" button, Red led will keep flash. Please open "Bluetooth setting" on your device and it will search automatically
4. There's a device "Bluetooth 3.0 Keyboard", click here and a set of four-digit code will be generated randomly
5. Enter four code above, Pairing completes. Red lights stop flashing, and turns off after 3 seconds

Function	LED Light Sequence
Battery Assembly	Red lights stop flashing, red light turns off after 3 seconds.
Pairing Start	Red light flashes.
Pairing Complete	Red lights stop flashing, red light turns off after 3 seconds.
Out of Range	Bright red light, turns off after 5 seconds.
Low Battery Indicator	Slow flashing red light, every 5 seconds confirmation

CLEANING, CARE, STORAGE & MAINTENANCE

- When it is not in use for a long time, we recommend turning off the keyboard power supply to extend the battery life
- In order to obtain a longer battery life, the keyboard is charged only when the keyboard power lamp is flashing.
- Charging under working conditions must use the original power line, such as using other data lines to charge during work may cause garbled and functional failure.

SPECIFICATIONS

Bluetooth Version	3.0
Keys	78 keys with function of 104 keys
Switch Life	5 million keystrokes
Batteries	2x AAA
Compatible OS	Android, Windows, iOS
Weight	0.5kg (Net) 0.8kg (Gross)
Dimensions	284 x 120 x 19mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555