

digitech

Wireless TWS Earphones with Bluetooth® 5.1 Technology



Model:
AA2167

Instruction Manual

CONTENTS

Before First Use	2
Box Contents	3
Product Diagram.....	3
LCD Display.....	4
Functions.....	4
Specifications.....	10
Warranty Information.....	12

BEFORE FIRST USE

Prior to using your product, please read all the safety and operating instructions thoroughly. Please ensure you follow the steps below before using the product. We recommend you keep the original packaging for storing the product when not in use.

Find a safe and convenient place to keep this instruction manual for future reference.

Unpack the product but keep all packaging materials until you have made sure your new product is undamaged and in good working order. Ensure you have all accessories listed in this manual.

BOX CONTENTS



2x TWS Earphones




1 x USB Charging Case



1 x USB-C Charging Cable

PRODUCT DIAGRAM



Feature	Description
1	Play/Pause / Call/ Volume Button Press to play or pause while playing music Press to accept, reject or redial last number called
2	Microphone/LED Status Indicator Microphone located in the right and left earphones for phone calls. Display the power and pairing status
3	LED Status Indicator Displays the power and pairing status of the earphones
4/5	Speaker Earphone speaker covered by a dustproof mesh
6	USB Power Socket (Rear) Connect to the USB charging cable and suitable USB power source
7	Charging Ports Charges the earphones
8	Earphone Case LED Battery Indicator Displays the current battery status of the earphone case

OPERATION

Bluetooth Pairing

1. Make sure the earphones are fully charged before use, pull both earphones out of the charging case.

NOTE: Press and hold the power button for up to 5 seconds to turn the earphones off.

2. The LED indicator should be flashing red and blue. Open the settings of your smart phone and ensure Bluetooth® is turned on.
3. Once your Bluetooth® is enabled; Scan for devices and the Bluetooth® name AA-2167 should appear. **Bluetooth® Name: AA-2167**
4. Press the AA-2167 on the Bluetooth® device list and your smartphone should show that it is connected.
5. You will hear a voice prompt from the earphones saying "Connected". The volume can be controlled by your smartphone or earphones. The battery status can also be shown in your Bluetooth settings.

NOTE: The earphones will automatically turn off after 3 minutes or if they're too far away from your device.

Bluetooth® Hands-Free

Function	Button
Answer Incoming Call	Press the play/call button to answer the current incoming call
Reject Incoming Call	Press the play/call button two times to reject the current incoming call
Hang Up Call	Once a call has been received; press the play/call button again to hang up
Google Assistant & Siri®	Press the play/call for up to 1.5 seconds to activate Google Assistant or Siri® on your smartphone. Your smartphone or tablet requires Google Assistant or Siri in order to work

Music Playback

Function	Button
Pause	Press the play/call button to pause the current music track
Play	Press the play/pause button again after pausing to resume the current music track
Next Track	Press the play / call button 2 times to skip to the next music track
Volume	Press the play / call button 3 times to turn the volume up or down

Charging Earphones

Insert the earphones into the earphone charging case to recharge them. The red LED should now be lit on the earphones to indicate charging

NOTE: The LED indicator will turn off once the charging has finished.

Charging Case

1. Insert the USB micro B charging cable in a 5VDC mains power adaptor (not included) or a suitable USB charging port such as a computer.
2. Insert the micro B USB plug into the USB power socket of the charging case.
3. The LED status indicator will flash blue once charging has started.
4. Once fully charged; the LED status indicator will turn to a solid blue.

TROUBLESHOOTING

Problem	Solution
Battery Won't Charge Or Power On	Connect to a suitable USB charging source such as a USB mains power adaptor or USB charging port and make sure it's correctly turned on.
	Make sure the battery is fully charged up to 2 hours and make sure the LED status indicator has turned off.
No Power / LED Indicator	Ensure the USB charging cable is connected properly to a USB charging port or USB charging adaptor.
	Check to see if your USB power source is working correctly.
No Audio	Ensure the volume is correctly turned up on your smartphone.
	Ensure the earphones are correctly paired and turned on.
	Turn the earphones off and on again, turn off the Bluetooth of your smartphone or tablet and turn back on.
	Type in the password "0000" if it asks you for one.

SAFETY

- Do not open the earphones or charging case of this product to prevent the unit from damage.
- Keep the earphones and earphone charging case away from high temperatures as it may damage the device.
- Do not expose the earphones or earphone charging case to water or liquids to prevent the unit from damage.

SPECIFICATIONS

Bluetooth® Version	5.1
Transmission Range	Up to 10m
Frequency Response	20Hz-20KHz
Sensitivity	102dB
Playback Time	Up to 4 Hours
Talk Time	Up to 3 Hours
Standby Time	Up to 60 Hours
Charging Time	Up to 90 Minutes
Battery	3.7V Li-ion, 30mA (Each Earphone) 3.7V Li-ion, 300mA (Battery Case)
Power	5VDC, 500mA (USB-C)
Dimensions	Earphones: 41(H) x 18(W) x 17(D)mm (Each) Case: 68(L) x 45(W) x 22(D)mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555